LETTO SLEEP+ ADJUSTABLE BED USER MANUAL

BRING COMFORT TO YOUR ROOM



READ THIS INSTRUCTION MANUAL AND OBSERVE SAFETY INSTRUCTIONS

Warnings

Please read the contents of this user manual carefully prior to using and assembling Letto Sleep+ Adjustable Bed ("the bed"). In the event the bed changes owners, please supply this instruction manual to the new owner.

Ensure that the bed's electrical components, such as the motors and controls, are properly connected and in good working condition. Keep electrical cords away from water sources and do not overload electrical outlets.

Do not exceed the weight limit per bed frame of 300kg, this limit is inclusive of the mattress and bedding. Exceeding this weight restriction could damage the bed and/or cause injury and will void the warranty.

Distribute body weight evenly over bed surface. Do not place entire weight on head or foot sections of the bed, during reposition and entering or exiting bed.

When adjusting the position of the bed, do so slowly and cautiously. Sudden and rapid movements may cause you to lose balance or become trapped between moving parts, resulting in injury. Keep your hands, fingers, and other body parts clear of the bed's mechanisms while adjusting.

Children or individuals with disabilities should not be allowed to operate the bed without adult supervision. They may not fully understand the potential dangers and may inadvertently activate moving parts or become trapped.

Do not allow any person or pet under the bed at any time.

If you have any medical conditions, such as back problems or circulatory issues, consult your healthcare provider before using an adjustable bed. They can provide specific guidance tailored to your needs and ensure it is safe for you to use.

Use a compatible Letto mattress that is designed for adjustable beds. Improper mattresses may inhibit the bed's movement and overload motors.

This bed is is designed for residential use only. It is not approved for hospital use and does not comply with hospital standards. The motors are not designed to operate continuously for more than (2) minutes in an (18) minute time period. Attempting to exceed this rating will shorten the life expectancy of the foundation and will void the warranty.

In order to claim warranty for your product, the bed must be serviced using only Letto original spare parts.

Letto warranty does not extend to damage caused by normal wear and tear, misuse or abuse, failure to properly clean and improper cleaning of the product. Damage caused by transportation, improper installations as per instructions and use of nonauthorised/nonstandard part repair or work carried out by unauthorised representatives.

As stated in our Warranty Statement, we provide a limited 10 (ten) year warranty. Please visit our website to view full Terms and Conditions www.letto.com.au

Assembly

1. Remove the bed from the carton and plastic bag.

2. Unfold the bed base upside down on the floor.

3. Remove and unpack all bed components.

4. Insert the safety pins.

5. Screw the six legs into the base. Note that by unscrewing each leg section, you can choose between three different heights.

6. Connect the power cord to the adapter and plug it into a nearby outlet.

7. Flip the bed base over onto its legs.

8. Attach the side and foot end mattress retainers.

9. Place the battery into the remote to operate the bed.





Components

- 1. Remote Control (2x AAA Battery Included)
- 2. Adaptor
- 3. Power Cable
- 4. Safety Pins
- 6. Adjustable Legs
- 7. Mattress Retainers







Operation & Troubleshooting

One Touch Pre Set Positions

TV watching TV while in bed
Lounge relax your body
Anti Snore prevent snoring
Zero Gravity helps with pain & pressure relief, blood circulation & breathing
Flat brings the bed back to a flat position

Memory Positions

In order to memorise new bed position, press and hold MI or M2 button for 2 seconds or until you hear 3 beeps.

Massage Mode

a. Upper Body Massage (3 intensity levels)
b. Lower Body Massage (3 intensity levels)
c. Change Massage Mode (3 massage modes)
d. Massage Timer (10min, 20min, 30min)
e. Turn Off Massage

Lights

f. Remote Control Flash Lightg. Under Bed Light

Back Up Battery Pack

Open Adaptor lid and add 2x 9V batteries to use bed base battery pack. 9V batteries are not supplied with the bed Adaptor.

Synchronize Both Bed Bases to One Remote

Pair remote control A to both bed bases

Remote Control Paring

Press Back Up and Leg Up button together and press Control Box Learn Button (also found on power lead), you will hear 3 beeps. Please note that each Remote Control comes already paired with each bed base.

Troubleshooting

Base has lost power and functions

- 1.Unplug the power cord, wait 30 seconds and plug back in to reset electric components.
- 2. Make sure that you are following the duty cycle of the motors (do not operate more than two minutes over an 18 minute period).
- 3. Check batteries in wireless remote control. Replace with two new AAA batteries if necessary.
- 4. The surge protection or the electrical outlet may be defective. Test the outlet by plugging in another working appliance.





Contact us support@letto.com.au www.letto.com.au